



FUSEBOX 1

- LOW BEAM  
15 AMP
- HI BEAM  
25 AMP
- RAD FAN  
25 AMP
- BRAKE  
10 AMP
- HEAD  
25 AMP
- HAZARD  
10 AMP

FUSEBOX 2

- PARK  
10 AMP
- E.C.U  
15 AMP
- RESERVOIR  
10 AMP
- REVERSE  
10 AMP
- FUEL PUMP  
15 AMP
- REAR FOG  
15 AMP

FUSEBOX 4

- MAIN  
40 AMP
- HORN  
10 AMP
- SEAT BELT  
7.5 AMP
- HANDBRAKE  
7.5 AMP
- ALTERNATOR  
10 AMP
- WATER PUMP  
10 AMP

FUSEBOX 3

- INDICATOR  
10 AMP
- WASHER  
25 AMP
- W/SCREEN  
15 AMP
- HEATER  
15 AMP
- GAUGES  
10 AMP
- WIPER  
15 AMP